

DUISBURG LED MOTHER AND CHILD LAMP

These instructions are provided for your safety.
Please read carefully before commencing work and retain for future reference.

SAFETY INFORMATION

- * The supply cable runs through the inside of the fitting. Take care not to place undue stress on the cable whilst unpacking to prevent the possibility of a poor connection.
- * If you are in any doubt consult a person competent to give advice on the assembly of electrical equipment.
- * If the external flexible cable of the lamp is damaged it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- * To prevent electrocution switch off at the mains supply before assembling or maintaining this product. Ensure the plug is not connected to any power supply and read instructions before assembly.
- * **Always unplug from the mains supply and allow the LED to cool down before handling.**

ASSEMBLY INSTRUCTIONS


1. Unpack floor lamp and remove all packaging material. Be careful that you do not scratch surface of the stems whilst removing wrapping.
2. Where required remove the plastic / cardboard cable protectors that are fitted at cable entry points inside stems and floor lamp base.
3. Screw middle stem clockwise into top stem. ① Take care to hold stems parallel to avoid cross threading. Hold the upper stem still and only rotate the lower stem, so as not to twist the cable.
4. Screw lower stem clockwise into middle stem. ② Take care to hold stems parallel to avoid cross threading. Hold the upper stem still and only rotate the lower stem, so as not to twist the cable.
5. Gently pull the cable out of the base, ③ offer the base onto the lower stem and rotate the base onto the stem whilst make sure threads do not cross, ④ if in doubt undo and start again.
6. Screw uplighter onto top stem then lock this into position ⑤ using hex screw and key provided. ⑥
7. Offer top section onto assembled sections and fit excess cable into the stem by forming into loops, screw the top section clockwise. ⑦
8. **Ensure all assembled sections are fully tightened.**
9. Use the spanner provided to fully lock the retaining nut under side of the base whilst taking care not to slip with the spanner. ⑧
10. Stand the floor lamp upright then make sure the assembled parts are sufficiently tightened.
11. Attach diffuser onto the up-lighter using the screws provided, ⑨ take care not to over tighten the screws.
12. Attach diffuser onto the reading light head using the screw provided, ⑩ take care not to over tighten the screws.
13. Unpack the electronic plug in driver module and plug the connector into the cable protruding from the floor lamp then lock these together by rotating outer ring.
14. Plug the electronic driver into the mains supply socket.
15. Your floor lamp is now ready for use.

Please retain this information leaflet for future reference

GENERAL INFORMATION

This floor lamp is designed for internal use only.

Do not use polish or an abrasive cleaner - just a soft dry cloth.



Depress button and release will switch LED lamp ON /OFF.

Depress button and release will switch LED lamp ON /OFF at the last light level.

Holding button depressed will cause LED to cycle through the light intensity until released.