

OUNGLE LED FLOOR LAMP

These instructions are provided for your safety.
Please read carefully before commencing work and retain for future reference.

SAFETY INFORMATION


- * If the flexible cable of this product is damaged it should be exclusively replaced by the manufacturer or a similar qualified person in order to avoid a hazard.
- * To prevent electrocution switch off at the mains supply before assembling or maintaining this floor lamp. Ensure the plug is not connected to any power supply and read instruction before assembly.
- * This floor lamp is supplied with plug in electronic driver and is suitable for 240 Volt ring mains.

ASSEMBLY INSTRUCTIONS

1. Unpack floor lamp and remove all packaging material. Be careful that you do not scratch surface of the stems whilst removing wrapping.
2. Where required remove the plastic / cardboard cable protectors that are fitted at cable entry points inside stems and floor lamp base.
3. Stand the floor lamp upright then make sure the assembled parts are sufficiently tightened.
4. Unpack the electronic plug in driver module and plug the connector into the cable protruding from the floor lamp then lock these together by rotating outer ring.
5. Plug the electronic driver into the mains supply socket.
6. Your floor lamp is now ready for use.

Depress button and release will switch LED lamp ON /OFF at the last light level.

Holding button depressed will cause LED to cycle through the light intensity until released.



Please retain this information leaflet for future reference

GENERAL INFORMATION

This floor lamp is designed for internal use only.

Do not use polish or an abrasive cleaner - just a soft dry cloth.